



ELECTRIC FRYER 15lt.

Pos	Код	Описание
0001	CR0686180	BASKET [C] FRYER 700
0002	MACM073100	HANDLE [C] MT/105
0003	CR0686210R	FRYER COVER [C] 15L.900
0004	CR0508560	SHELF GRID [C] FRYER FQG 41/61
0005	MA15119299	GRAIN [C]
0006	MACM021600	RING NUT [C]
0007	MA1037111300	MICROSWITCH [C]
0009	MACM187301	CONTACTOR [C]
0010	CR0589660	THERMOSTAT [C]
0011	CR0587650	GASKET [C] SHAFT
0013	CR0587500	ORANGE PILOT LAMP [C]
0014	CR1095040	KNOB [C] SHAFT E15 D. 6
0015	CR0580460	BUSH [C]
0016	CR1095190	LABEL FRYER [C]
0017	CR0588510	GASKET [C] CONTROL PANEL 900
0018	CR0588850	FLANGE [C]
0019	MACM097701	THERMOSTAT [C] 230Â°C
0020	CR0585850	EXTENSION [C] DRAIN FRYERS 23L
0021	CR0733340	VALVE [C]
0022	MA1878400	TERMINAL BLOCK [C]
0024	MA6086113	FOOT ASSEMBLY [C] H. 200
0025	CR0582130	NUT [C]
0026	CR0582140	GASKET [C]
0027	CR0582120	HEATING ELEMENT BUSH [C] FOR PASTA COOKERS
0028	CR0583860	RESISTENZA FRIGGITRICE 15L. 230V (KB)
0029	MA1033515800	ELASTIC COUPLER [C]
0030	MACM012401	NUT [C] M10X1
0031	MACM097900	GASKET OR [C] THERMOSTAT BULB
0032	MACM099200	GASKET [C] HEATING ELEMENT
0033	MACM200100	GREASE [C]
0034	CR0689390	LIFTING DEVICE [C] HEATING ELEMENT FRYER 15L